




• Cannot be used in feeder:
• Ne pas utiliser dans le chargeur:
• Kann nicht in der Zufuhr verwendet werden:
• No se pueden usar en el alimentador:
• Non possono essere posizionati nell'alimentatore:



• Face up originals
• Originaux face dessus
• Originale mit zu kopierender Seite nach oben
• Originales cara arriba
• Originali rivolti in su



! • When streaks appear
• Lorsque des lignes apparaissent
• Wenn Streifen auftreten
• Cuando aparezcan rayas
• Quando compaiono delle strisce



A5

A5
A4

A4
A3










Canon

CAUTION
ATTENTION
ATTENZIONE

▲ If streaks appear on your copies, clean the narrow glass plate with the cloth supplied with the device, or with a cloth dampened with water and well wrung out.

❗ Opening and then closing the feeder/paper cover will activate the copying light. Staring at the copying light for prolonged periods may cause eye fatigue.

C3330i



Navigation and function buttons:

- 1, 2, 3 (ABC, DEF)
- 4, 5, 6 (GHI, JKL, MNO)
- 7, 8, 9 (PQRS, TUV, WXYZ)
- * (Star), 0, # (Hash)
- Log In/Out (ID)
- C (Copy)
- Yellow button (Cancel/Stop)
- Green button (Start/Go)
- Red button (Stop/Cancel)

FORERUNNER
ADVANCE

